
# 200W DMX512 & RDM LED Driver(constant voltage) 09.200RDC.04765



Important: Read All Instructions Prior to Installation

#### **Function introduction**



#### **Product Data**

|         | LED Channel                  | 4                                       |                                       |  |
|---------|------------------------------|---|---------------------------------------|--|
|         | DC Voltage                   | 12V DC                                  | 24V DC                                |  |
|         | Max. Current                 | Max. 8.3A/ch,<br>ch1+ch2+ch3+ch4=16.6A  | Max. 4.1A/ch,<br>ch1+ch2+ch3+ch4=8.4A |  |
| Output  | Voltage Tolerance            | ±1%                                     |                                       |  |
|         | Rated Power                  | max. 200W                               |                                       |  |
|         | Voltage Range                | 100-277V AC                             |                                       |  |
|         | Frequency Range              | 50/60Hz                                 |                                       |  |
|         | Power Factor (Typ.)          | > 0.98 @ 230VAC                         |                                       |  |
|         | Total Harmonic<br>Distortion | THD ≤ 15% (@ full load / 230VAC)        |                                       |  |
| Input   | Efficiency (Typ.)            | 93% @ 230VAC full load                  |                                       |  |
|         | AC Current (Typ.)            | 2.3A @ 100VAC, 1A @ 230VAC, 0.9A@277VAC |                                       |  |
|         | Inrush Current (Typ.)        | COLD START Max. 65A at 230VAC           |                                       |  |
|         | Leakage Current              | < 0.5mA/230VAC                          |                                       |  |
|         | Standby Power<br>Consumption | < 1W                                    |                                       |  |
|         | Dimming Interface            | DMX/RDM                                 |                                       |  |
| Control | Dimming Range                | 0%-100%                                 |                                       |  |
| Control | Dimming Method               | Pulse Width Modulation                  |                                       |  |
|         | Dimming Curve                | Linear, Logarithmic                     |                                       |  |

| Protection      | Short Circuit               | Yes, recovers automatically after fault condition is removed                  |  |
|-----------------|-----------------------------|---|--|
|                 | Over Current                | Yes, recovers automatically after fault condition is removed                  |  |
|                 | Over Temperature            | Yes, recovers automatically after fault condition is removed                  |  |
|                 | Working Temp.               | -20°C ~ +45°C   |  |
| F               | Max. Case Temp.             | 85℃   |  |
| Environment     | Working Humidity            | 10% ~ 95% RH non-condensing   |  |
|                 | Storage Temp.<br>& Humidity | -40°C ~ +80°C, 10% ~ 95% RH   |  |
|                 | Safety Standards            | UL8750, CAN/CSA C22.2 No. 250.13-14,<br>ENEC EN61347-1, EN61347-2-13 approved |  |
|                 | Withstand Voltage           | I/P-O/P: 3.75KVAC   |  |
| Safety &<br>EMC | Isolation Resistance        | I/P-O/P: 100M Ohms / 500VDC / 25°C / 70% RH                                   |  |
|                 | EMC Emission                | EN55015, EN61000-3-2, EN61000-3-3   |  |
|                 | EMC Immunity                | EN61547, EN61000-4-2,3,4,5,6,8,11, surge immunity Line-Line 1KV               |  |
| Others          | MTBF                        | 193.6K hrs min. @ 230VAC full load and 25℃<br>ambient temperature             |  |
|                 | Dimension                   | 270*79*39mm (L*W*H)   |  |
|                 |                             |   |  |

- Dimmable LED driver with rectangle metal case
- 4 channels 12/24VDC constant voltage output
- · Class 1 power supply, full isolated metal case
- · Built-in two-stage active PFC function
- PF > 0.98, Efficiency > 93%
- Low standby power < 1W
- · Built-in DMX dimming interface
- Enable to set DMX address, DMX channel quantity, PWM output resolution (8 bit or 16 bit)
- · Enable to set PWM output frequency, GAMMA ray dimming curve value and DMX decoding mode
- DMX512(2008), DMX512-A and RDM V1.0 (E1.20 2006 ESTA Standard)
- · Compliant with Safety Extra Low Voltage standard
- Short circuit, over load, over temperature protection
- IP20 rating, suitable for indoor LED lighting applications
- · 5 years warranty

## Safety & Warnings

- DO NOT install with power applied to the device.
- DO NOT expose the device to moisture.

#### **Button introduction**

Up, Down button is for menu selection. After power on the decoder, if keep on clicking Up button, you will find below menu on display:

DMX signal indicator • :: When DMX signal input is detected, the indicator on

the display following after  $\frac{1}{2}$  turns on red  $\frac{1}{2}$   $\times \times \times$ 



XXX Means DMX address. factory defaults setting is 001.

XX Means DMX channels quantity.

XX Means Bit (8bit or 16bit). factory defaults setting is 16bit

Real XX Means output PWM frequency. factory defaults setting is 1K HZ

Baxx Means output dimming curve gamma value, factory defaults setting is ga 1.5

Hans Decoding mode, factory defaults setting is dp1.1

Press and hold down both buttons Back + Enter simultaneously over 5 seconds until the display go off to restore to factory default settings .

# 1. DMX address setting:

select menu P XXX, click button "Enter", display flashes, then click or hold button "Up" / "Down"

to set DMX address (click is slow, hold is fast.), then click button "Back" to confirm.

# 2. DMX channel quantity setting:

Select menu  $\{ \{ \} \} \}$  xx, click button "Enter", display flashes, then click button "Up" / "Down"

to set DMX channel quantity, then click button "Back" to confirm.

For example the DMX address is already set 001.

CH01=1 DMX address for all the output channels, which are all address 001.

CH02=2 DMX addresses, output 1&3 is address 001, output 2,4 is address 002

CH03=3 DMX addresses, output 1, 2 is address 001,002, output 3,4 is address 003

CH04=4 DMX addresses, output 1,2,3,4 is address 001,002,003,004

### 3. PWM output resolution Bit setting:

select menu  $\{x \in X \mid x \in X \}$ , click button "Enter", display flashes, then click button "Up" / "Down"

# DMX address is 001, CH01

| DMX Console<br>Slider number<br>DMX channel | dp1.1                     | dp2.1                           |
|---|---------------------------|---------------------------------|
| 1   | for all output<br>dimming | for all output<br>dimming       |
| 2   | No use                    | for all output<br>micro dimming |

#### DMX address is 001, CH02

| DMX Console<br>Slider number<br>DMX channel | dp1.1                     | dp2.1                           | dp3.2                     |
|---|---------------------------|---------------------------------|---------------------------|
| 1   | for output<br>1&3 dimming | for output<br>1&3 dimming       | for output 1&3<br>dimming |
| 2   | for output 2,4<br>dimming | for output 1&3<br>micro dimming | for output 2,4<br>dimming |
| 3   |                           | for output 2,4<br>dimming       | for all output<br>dimming |
| 4   |                           | for output 2,4<br>micro dimming |                           |

#### DMX address is 001, CH04

| DMX Console<br>Slider number | dp1.1                   | dp2.1                         | dp5.4                            | dp6.4                            |
|------------------------------|-------------------------|-------------------------------|----------------------------------|----------------------------------|
| DMX channel                  |                         |                               |                                  |                                  |
| 1                            | for output<br>1 dimming | for output<br>1 dimming       | for output 1<br>dimming          | for output 1<br>dimming          |
| 2                            | for output 2<br>dimming | for output 1<br>micro dimming | for output 2<br>dimming          | for output 2<br>dimming          |
| 3                            | for output 3<br>dimming | for output 2<br>dimming       | for output 3<br>dimming          | for output 3<br>dimming          |
| 4                            | for output 4<br>dimming | for output 2<br>micro dimming | for output 4<br>dimming          | for output 4<br>dimming          |
| 5                            |                         | for output 3<br>dimming       | for all output<br>master dimming | for all output<br>master dimming |
| 6                            |                         | for output 3<br>micro dimming |                                  | strobe effects                   |
| 7                            |                         | for output 4<br>dimming       |                                  |                                  |
| 8                            |                         | for output 4<br>micro dimming |                                  |                                  |

#### The supported RDM PIDs are as follows:

DISC\_UNIQUE\_BRANCH
DISC\_UN\_MUTE
DEVICE\_INFO
DMX\_START\_ADDRESS
IDENTIFY\_DEVICE
SOFTWARE\_VERSION\_LABEL
DMX\_PERSONALITY
DMX\_PERSONALITY\_DESCRIPTION
SLOT\_INFO
SLOT\_DESCRIPTION
MANUFACTURER\_LABEL
SUPPORTED\_PARAMETERS

to choose 08 or 16 bit, then click button "Back" to confirm.


### 4. output PWM frequency setting:

select menu  $\bigcap_{i=1}^n \bigcap_{j=1}^n \bigcap_{i=1}^n \bigcap_{j=1}^n \bigcap_{i=1}^n \bigcap_{j=1}^n \bigcap_{i=1}^n \bigcap_{j=1}^n \bigcap_{i=1}^n \bigcap_{j=1}^n \bigcap_{j=1}^n \bigcap_{j=1}^n \bigcap_{i=1}^n \bigcap_{j=1}^n \bigcap_{j=1}^n \bigcap_{i=1}^n \bigcap_{j=1}^n \bigcap_{i=1}^n \bigcap_{j=1}^n \bigcap_{$ 

#### 5. output dimming curve gamma value setting:

select menu  $\bigcap \chi \chi$ , click button "Enter", display flashes, then click or hold button "Up" / "Down"

to choose 0.1~9.9, then click button "Back" to confirm.



#### 6. DMX decoding mode setting:

Select menu XX, click button "Enter", display flashes, then click or hold button "Up" / "Down" to choose the decoding mode, then click button "Back" to confirm. "dPxx" means the DMX address quantity used for control of corresponding PWM output channel quantity. 1st "x" is DMX address quantity, 2nd "x" is PWM channel quantity. Micro dimming: the micro dimming effect can only be visible when the dimming curve gamma value is set lower than 1.4, and the lower the value is, the more visible the micro dimming effect will be.

DMX address is 001, CH03

| DMX Console<br>Slider number<br>DMX channel | dp1.1                     | dp2.1                           | dp4.3                            | dp5.3                            |
|---|---------------------------|---------------------------------|----------------------------------|----------------------------------|
| 1   | for output<br>1 dimming   | for output<br>1 dimming         | for output 1<br>dimming          | for output 1<br>dimming          |
| 2   | for output 2<br>dimming   | for output 1<br>micro dimming   | for output 2<br>dimming          | for output 2<br>dimming          |
| 3   | for output 3,4<br>dimming | for output 2<br>dimming         | for output 3,4<br>dimming        | for output 3,4<br>dimming        |
| 4   |                           | for output 2<br>micro dimming   | for all output<br>master dimming | for all output<br>master dimming |
| 5   |                           | for output 3,4<br>dimming       |                                  | strobe effects                   |
| 6   |                           | for output 3,4<br>micro dimming |                                  |                                  |

# The data definitions for strobe channel are as follows:

{0, 7},//undefined {8, 65},//slow strobe-->fast strobe {66, 71},//undefined {72, 127},//slow push fast close {128, 133},//undefined {134, 189},//slow close fast push {190, 195},//undefined

{196, 250}.//random strobe

{251, 255},//undefined

#### Restore to Factory Default Setting

Press and hold down both "Back" and "Enter" keys until the digital display turns off, then release the keys, system will reset and the digital display will turn on again, all settings will be restored to factory default.

Default settings are as follows:

DMX Address Code: a001

DMX Address Quantity: SW1=0: ch04,

SW1=1:ch03


PWM Resolution Mode: bt16

PWM Frequency: pf01

Gamma: ga1.5

Decoding Mode: dp1.1

# Wiring diagram



# **Product Dimension**

